

DVR Systems

Local Network Setup

Automatically Assign an IP address in to the DVR

All Zmodo DVR's have the capability of automatically assigning an IP address as long as the unit is connected to a router with an ethernet cord.

1) To auto assign an IP address in your DVR, access the **Main Menu** and go in to the **Network Settings**.

Select **DHCP** (auto assign IP) and select **Apply**. Restart the system after the setting has been saved.

Examples:

H9104V, H9108V, H9116UVDH

DVR Systems

NETWORK

Network SubStream DDNS Email Mobile

Type	DHCP ▾
Client Port	09000
HTTP Port	00080
UPNP	Disable ▾

Default Apply Exit

H9114V, H9118V

DVR Systems

System Record Video **Net** Alarm Maintenance Save

NETWORK DHCP

IP ADDRESS 172 . 16 . 4 . 245

SUBNET MASK 255 . 255 . 255 . 0

GATEWAY 172 . 16 . 4 . 1

HTTP PORT 80

COMMAND PORT 5050

MEDIA PORT 6050

Next page >

Set the gain way of network address.
It will take effect after being saved.

H8114V, H8118UV

DVR Systems

NETWORK SETUP ✕

AUTO ASSIGN IP (DHCP) ENABLE UPNP

ETHERNET IP

NETMASK

GATEWAY

DNS

SERVER PORT HTTP PORT

DDNS SERVER ▼ MOBILE PORT

DOMAIN NAME

ACCOUNT PASSWORD

PPPOE AUTO STARTUP

PPPOE IP

ACCOUNT

PASSWORD

H9124V

DVR Systems

TCP/IP TYPE **DHCP**

MEDIA PORT **09000**

WEB PORT **00080**

IP Addr 192.168.001.100

SUBNET MASK 255.255.255.000

GATEWAY 192.168.001.001

DNS1 172.016.004.010

DNS2 **192.168.001.001**

UPNP **ON**

DDNS SETUP **DEFAULT** **APPLY** **EXIT**

2) Once the DVR boots back up, go back in to the Network Settings and write down the IP address, Gateway (router's IP), and all port numbers. Keep this information for the Remote Network Setup.

DVR Systems

Checking Your Connection

3) Make sure the router is powered on.

4) Make sure the light on the router port that the ethernet cable is connected to is on.

5) Make sure the light on the DVR port is on.

6) Configure Internet Explorer on the computer that is connected to the router that the DVR is connected to using the procedures on this link: [HERE](#)

7) Open Internet Explorer and enter the IP address of the DVR, to make sure you can see the login screen. If you can, your DVR is successfully communicating with your router.

8) After the confirming your connection, go back in to the Network Settings and change the Type back from **DHCP** to **Static**. Add 20 to the last set of digits in the IP address. Input this new IP address, Gateway (router's IP), and all port numbers. Save the settings and restart the DVR. This needs to be set to Static, otherwise, if your power goes out, your DVR may end up with a different IP address than the one that we will forward later on.

Your DVR can now be viewed over your local network.

To view your DVR from outside of your local network visit the Remote Network Setup: [HERE](#)

Unique solution ID: #1006
Author: Jamie Alksnis

DVR Systems

Last update: 2014-04-11 10:02