ZMD-DR-SFN6

I can only view 4 cameras on my 9128 or SFN6

The ZMD-DR-SFN6 is unable to view all 16 cameras at once. Instead, you have to cycle through the cameras, 4 at a time.

To do this, keep clicking the button that says '4' in the upper-right corner of the interface.

Cameras 1-4



Cameras 5-8

(c) 2024 Jeremy Schultz <itmanager@eptco.com> | 2024-03-29 00:24
URL: https://kb.zmodo.com/index.php?action=artikel&cat=8&id=113&artlang=en

ZMD-DR-SFN6



Cameras 9-12



(c) 2024 Jeremy Schultz <itmanager@eptco.com> | 2024-03-29 00:24
URL: https://kb.zmodo.com/index.php?action=artikel&cat=8&id=113&artlang=en

Cameras 13-16



You can just keep hitting the '4' button and rotate through all 16 cameras that you have hooked up.

Unique solution ID: #1112
Author: Alex Crewell
Last update: 2013-08-16 23:47

(c) 2024 Jeremy Schultz <itmanager@eptco.com> | 2024-03-29 00:24
URL: https://kb.zmodo.com/index.php?action=artikel&cat=8&id=113&artlang=en