

DVR-H9116UVDH

My Camera Images are "Rolling"

Camera Images are "Rolling"

All DVRs

If the camera images are "Rolling" **and/or** the DVR is displaying in only black and white, the DVR Video System is in PAL mode. To change the Video System go into the Audio/Video Setup and change it from PAL to NTSC.

Unique solution ID: #1023

Author: Patricia Pyle

Last update: 2014-07-18 10:49