Default Admin Passwords for Zmodo DVR Units

The following is a comprehensive list of all **default** DVR passwords for current and previous Zmodo DVR models:



SBN Series (H9104V, H9108V, ZMD-DD-SBN4, ZMD-DD-SBN8, ZMD-DD-SBN6)


SAN Series (H9114V, H9118V, ZMD-DD-SAN4, ZMD-DD-SAN8)

Login: Admin

Password: 111111 **OR** 888888

Click Here for more articles relating to this DVR.

(c) 2024 Jeremy Schultz <itmanager@eptco.com> | 2024-03-29 06:30
URL: https://kb.zmodo.com/index.php?action=artikel&cat=0&id=12&artlang=en




H8100 Series (H8104UV, H8108UV, H8106UV)

H8110 Series (H8114UV, H8118UV, H8116UV)

Login: admin

Password: 666666

Click Here for more articles relating to this DVR.



ZMD-DT-SFN6

(c) 2024 Jeremy Schultz <itmanager@eptco.com> | 2024-03-29 06:30
URL: https://kb.zmodo.com/index.php?action=artikel&cat=0&id=12&artlang=en

Login: admin

Password: (Blank) or 111111

Click Here for more articles relating to this DVR.



SCN Series(ZMD-DT-SCN4, ZMD-DT-SCN8)

SEN Series(ZMD-DH-SEN6)

Login: admin

Password: (Blank) or 111111

Click Here for more articles relating to this DVR.

(c) 2024 Jeremy Schultz <itmanager@eptco.com> | 2024-03-29 06:30
URL: https://kb.zmodo.com/index.php?action=artikel&cat=0&id=12&artlang=en



NVR Series: Basic NVR(ZMD-NV-SBN4), Mini-NVR(ZH-NA04-W), and POE-NVR(ZP-NC14-P)

Login: admin

Password: 111111

Click Here for more articles relating to the Basic NVR.

Click Here for more articles relating to the Mini-NVR.

Click here for more articles relating to the POE-NVR.

If your DVR is not listed in this article, then your DVR does not prompt you for a password or have one by default. You will need to look up your DVR and follow the password reset guidelines if you do not know it.

Unique solution ID: #1011
Author: Patricia Pyle
Last update: 2014-04-08 08:39

(c) 2024 Jeremy Schultz <itmanager@eptco.com> | 2024-03-29 06:30
URL: https://kb.zmodo.com/index.php?action=artikel&cat=0&id=12&artlang=en