

Accessories

Installation Guide for the NE-PSE104 4 Port POE Injector





User Guide

4 PORT 48V POE INJECTOR


The intended use of this product is to supply power and video stream connection to Power Over Ethernet (POE) IP Cameras so that your POE IP Cameras may connect either to an NVR or to an internet connection for remote viewing.

****This product is compatible with Zmodo brand 48V POE IP Cameras and also non-Zmodo brand 48V POE IP Cameras.**

Standard Operation: Connect POE IP Cameras to a Router



Standalone Operation: Connecting POE Cameras to Your NVR Without a Router or Internet Connection



Need some help?

Check out our online resources and installation tips at kb.zmodo.com. We're also on YouTube! Check out our "Zmodo Tech Support" official YouTube channel.

Supported Zmodo POE IP Camera Models that are compatible with this 48V POE Injector:

ZP-IBG11-P	ZP-IDR13-PA
ZP-IBG14-P	ZP-IBH13-P
ZP-IPD15-P	

****List may not include all compatible models. All 48V POE IP Cameras supported.**

Unique solution ID: #1379
Author: Amanda Mayer
Last update: 2015-10-06 16:16