

# ZMD-DT-SCN4

## PTZ settings and cruise with DT-SCN series DVR systems


Cruise between preset points as follows:

Step1: In picture below, the directional control will turn the PTZ camera to the designated location.



Step 2: Once you have the desired position, click Cruise buttons, then write proper value into the Cruise Line and Preset Points blank, then click "SET" which will open the PTZ Config menu.

# ZMD-DT-SCN4



The image shows a 'PTZ Config' window with a dark background. On the left, there is a list of functions: 'Function', 'Preset' (highlighted in red), 'Tour', 'Pattern', and 'Border'. To the right of these functions are input fields: 'Preset' with the value '0', 'Interval' with the value '3', and 'Patrol No.' with the value '0'. Below these fields are two buttons: 'Set' and 'Del Preset'.

Click in the preset box and give a number to indicate the current position of the camera. Repeat using a different number for each preset position until you have all presets entered.

Step 3: Click on "Tour". Here you can add the preset points to the desired pattern of movement known as a "tour". Once the presets are added, return to the PTZ control and click on "Page switch". You can now click on "tour" and the PTZ camera begins to work on the cruise line. Click Stop button to stop cruise.

Unique solution ID: #1355

Author: Jamie Alksnis

Last update: 2015-03-27 12:40