

DVR-H9104V / DVR-H9104UV

Enable Motion Recording on H91XX Series DVRs

To enable motion recording on a 91XX series DVR, we must first configure motion detection. After motion detection is enabled, we will change our recording settings to match.

Configure Motion Detection

1. Go to **Main Menu**
2. Go to **Device**
3. Go to **Motion**
4. Enable Motion
5. Choose Sensitivity Level. The higher the number, the more sensitive the camera is.
6. Copy Settings to All channels.

Configure Recordings Settings

1. Go to **Main Menu**
2. Go to **Record**
3. Change **Record Mode** from "**Always**" to "**Schedule**"
4. Click "**Schedule**"
5. Click "**Alarm**"
6. Highlight all boxes as Red
7. Copy Settings to All Channels.

If you go to the live feed, you should now see the cameras and the letter M on the screens when they detect motion.

Unique solution ID: #1156

Author: Alex Crewell

Last update: 2013-08-20 23:26