ZMD-DT-SCN8 How to connect the SCN4, SCN8, and SEN6 to the General CMS software

This is a tutorial on how to connect DVRs with the SKU numbers SCN4, SCN8 and SEN6 to the General CMS software that came with the DVR units. If you have misplaced the disc, click <u>here</u> to download the software.

1. When you first open the software, there will be a warning that there is no device connected.



Click **OK** and then select the option for **System** as shown below.

СМS		- = ×
Device	Monitor	Time
		14:17:26 2014-04-29
		PTZ
		Zoom Zoom Focus Iris Pan Pan
	Type Date Device User Describe	Color
		System
		PlayBack
		W Advance
<u> </u>		Signat LogOut

2. Select the option for **Device Manager**.

CMS		- = ×
Device	Monitor	Time
		14:16:12 2014-04-29
		System
		۲
		Device Manager
		Local Config
		Remote Config
		88
		Account
		Local Log
		PTZ
	Type Date Device User Describe	Color
		System
		PlayBack
		Advance
୍ର୍ଟ		25 LogOut

3. This should open up a new window. Select Add Area.



4. For the **Zone** enter a description of the location of the DVR, for example Home or Work. Then click **OK**. This is to help organize your DVRs if you have multiple DVRs in different locations.

Device Manager							×
(\$	0	Î				
ADD AREA	ADD DEVICE	MODIFY	DELETE	Devices impor	tDevices export	Connection Tes	t
	Zone Zone Up Zone	Test OK		Cancel	×		
			ОК				

5. The zone you created will apear in the Zone List. Select the zone that you created, and then the option to **Add Device** will appear.



6. Before adding the new device, the DVR should already be setup for local or remote access. You will also need all the IP addresses, port numbers, and login information already setup on your DVR.

- Name: this can be whatever you like it to be
- IP Address:
 - If you are on the same local network, you will use your local IP address that should be listed in the Network section on the DVR (Usually 192.168.x.x or 10.0.x.x)
 - If you are away from the location, you will use your External or Public IP address.
- Port: By default it should be 34567, unless it has been changed on DVR's network settings
- Username/Password: This will be the username and password you use to access the DVR.
 - It may be the administrator username and password for full privileges.
 - It can aslo be a custom username and password that was created for specific users with limited access.

Device Manager	×					
G	Edit					
ADD AF	NO. IP Address Port MAC Vendor on Test					
ζώ Zone ζώ Τ	IP Search Add Device EditDevice Device Name Test LoginType IP Address Domain ARSP Cloud IP Address · · · Port 34567 User Name admin Password ****** Zone Test Vendor H264DVR V					
ОК						

Once you have all that information filled out. Click **OK** and you should see your Device Name that you created listed underneath the Zone. Click **OK** again to go back to main screen.

7. You can now d**ouble-click** on the Device Name listed under the Device List. You should see on the bottom that it says **Connect Successful**, and your camera channels will appear under the DVR Device Name.

CMS						- 🔳 ×
Device				Monitor		Time
E Test ✓ Test ✓ CAM01 ✓ CAM02 ✓ CAM03 ✓ CAM04						14:22:51 2014-04-29
Le Crimor						PTZ
						Zoom Focus Iris
						Pan Preset
				25 36	64 🔀 🎼 📉	PTZ
	Туре	Date	Device	User	Describe	
	Video	2014-04-29 14:22:18	Test	admin	Connect successful	System
	Video	2014-04-29 14:22:16	Test	admin	Connect successful	PlayBack
						- Noybuck
	_					Advance
9	C					LogOut

8. To connect to the cameras, right-click on the Device Name and select the option for **Connect all Video**.

- Choose the **Main Stream** if you are local or want higher quality video, but this may take longer to load.
- The **Extra Stream** will give you a smoother image with a lower quality image.

You can also open each channel individually by first selecting a window with the green outline. Then double-click on one of the channels, for example CAM01, and the channel will appear in that window. Repeat the process for the other channels.

Unique solution ID: #1314 Author: Ed Lamont Last update: 2015-03-20 17:02