

# DVR Systems

## Disable Alarms on DVR-H9124V/8V and SFN6

If your DVR is beeping non stop, follow this guide in order to disable all of the alarms.

**Step 1:** Right click on the mouse and select 'Main Menu'



**Step 2:** Select Advanced

# DVR Systems



**Step 3:** Select Alarm

# DVR Systems



**Step 4:** Change 'Alarm Manage Output' to 05 and also change 'Buzzer' to 05

# DVR Systems

I/O CHANNEL	CH1	CH2	CH3	CH4
I/O ALARM	NO	NO	NO	NO
HDD LOSS	OFF	HDD SPACE		OFF
VIDEO LOSS	OFF			
ALARM MANAGE OUTPUT	OS	BUZZER	OS	
Post Alarm Recording				1MIN


**EMAIL SETUP**

Alarm duration time setup

NEXT PAGE DEFAULT APPLY EXIT


**Step 5:** Hit 'Apply' at the bottom of the page

# DVR Systems



**Step 6:** Hit 'Ok' when the system says 'Save Successfully'

# DVR Systems



The alarms on the DVR should have stopped beeping now.

Unique solution ID: #1113  
Author: Alex Crewell  
Last update: 2013-08-17 00:16