ZMD-DT-SJN6 Setting the date and time on my P2P system

From the main menu select "General Settings". On the left side, select "Date & Language"

			General Settings
8	Account Management		
ŝ	Date & Language	Enable NTP (Network Time Protocol)	
-		Time Zone	Auto
•	Display Settings	System Time	04 - 23 - 2015 09 : 41 : 47
	System Log	Time Format	12 Hour
-	Disk Drive Info	Date Format	MM-DD-YYYY
	System Settings	Sync Camera Time	
•	Help & FAQ	Language	English

The "System Time" must be set in using a 24 hour clock.

For AM you would use numbers from 1-12 for the hour and for PM you would use 13-23.

The "time format" setting that allows you to select between the 12 and 24 hour clock only refers to the on screen display.

You can also set the date and select the display format. You can choose to have the display set in different formats as month/day/year or day/month/year. Unique solution ID: #1359 Author: Jamie Alksnis Last update: 2015-04-23 14:37