

NVR and IP Cameras

Email setup for dvr's

Email Alert Settings

Gmail Email Alert Settings

****Before using your Gmail account as your SMTP server, be sure that you have enabled Gmail POP3 or Gmail IMAP through settings in your Gmail Account.****

If you are receiving an error with gmail, please be sure to allow less secure apps in your gmail account settings. Here is a link on allowing less secure apps.

<https://support.google.com/accounts/answer/6010255?hl=en>

SSL : Enable

SMTP Server : smtp.gmail.com

SMTP Port : 465 or 587

Sender : "your gmail email address" (ex. johndoe@gmail.com)

Password : "your gmail password"

Reciever : "your email address" (ex. johndoe@gmail.com)

Yahoo Email Alert Settings

****Before using your Yahoo! Mail account as your SMTP server, be sure that you have enabled Web&POP Access in your Yahoo! Mail Account(go to Options>Pop&Forwarding)****

SSL : Enable

SMTP Server : smtp.mail.yahoo.com

SMTP Port : 465 or 587

Sender : "your yahoo email address" (ex. johndoe@yahoo.com)

Password : "your yahoo password"

NVR and IP Cameras

Receiver : "your email address" (ex. johndoe@yahoo.com)

Outlook.com (formerly Hotmail or MSN) Email Alert Settings

SSL : Enable

SMTP Server : smtp-mail.outlook.com

SMTP Port : 587

Sender : "your email address" (ex. johndoe@hotmail.com or johndoe@live.com)

Password : "your password"

Receiver : "your email address" (ex. johndoe@hotmail.com or johndoe@live.com)

AOL Email Alert Settings

SSL : Enable

SMTP Server : smtp.aol.com

SMTP Port : 587

Sender : "your aol email address" (ex. johndoe@aol.com)

Password : "your aol password"

Receiver : "your email address" (ex. johndoe@aol.com)

Unique solution ID: #1115

Author: Alex Crewell

Last update: 2014-06-25 18:49