

# DVR-H9124V

## Disable Alarms on DVR-H9124V/8V and SFN6

If your DVR is beeping non stop, follow this guide in order to disable all of the alarms.

**Step 1:** Right click on the mouse and select 'Main Menu'



**Step 2:** Select Advanced

# DVR-H9124V




**Step 3:** Select Alarm

# DVR-H9124V



**Step 4:** Change 'Alarm Manage Output' to 0S and also change 'Buzzer' to 0S

# DVR-H9124V




The screenshot shows a blue-themed menu for the DVR-H9124V. At the top left is a red alarm bell icon. The menu is organized into several sections:

- I/O CHANNEL:** CH1, CH2, CH3, CH4
- I/O ALARM:** NO (dropdown) for each channel.
- HDD LOSS:** OFF (dropdown)
- HDD SPACE:** OFF (dropdown)
- VIDEO LOSS:** OFF (dropdown)
- ALARM MANAGE OUTPUT:** OS (dropdown, highlighted in green)
- BUZZER:** OS (dropdown)
- Post Alarm Recording:** 1MIN (dropdown)

Below these settings is a section titled **EMAIL SETUP**. Underneath, there is a red alarm bell icon followed by the text **Alarm duration time setup**. At the bottom of the menu are four buttons: **NEXT PAGE**, **DEFAULT**, **APPLY**, and **EXIT**.

**Step 5:** Hit 'Apply' at the bottom of the page


# DVR-H9124V



**Step 6:** Hit 'Ok' when the system says 'Save Successfully'



# DVR-H9124V



The alarms on the DVR should have stopped beeping now.

Unique solution ID: #1113  
Author: Alex Crewell  
Last update: 2013-08-17 00:16