

ZMD-DT-SCN4

PTZ settings and cruise with DT-SCN series DVR systems

Cruise between preset points as follows:

Step1: In picture below, the directional control will turn the PTZ camera to the designated location.



Step 2: Once you have the desired position, click Cruise buttons, then write proper value into the Cruise Line and Preset Points blank, then click "SET" which will open the PTZ Config menu.

ZMD-DT-SCN4



The image shows a 'PTZ Config' window with a dark background. On the left, there is a list of functions: 'Function', 'Preset', 'Tour', 'Pattern', and 'Border'. The 'Preset' option is highlighted with a red background. To the right of this list, there are input fields for 'Preset' (containing '0'), 'Interval' (containing '3'), and 'Patrol No.' (containing '0'). Below these fields are two buttons: 'Set' and 'Del Preset'.

Click in the preset box and give a number to indicate the current position of the camera. Repeat using a different number for each preset position until you have all presets entered.

Step 3: Click on "Tour". Here you can add the preset points to the desired pattern of movement known as a "tour". Once the presets are added, return to the PTZ control and click on "Page switch". You can now click on "tour" and the PTZ camera begins to work on the cruise line. Click Stop button to stop cruise.

Unique solution ID: #1355

Author: Jamie Alksnis

Last update: 2015-03-27 12:40