DVR-H9104V / DVR-H9104UV Enable Motion Recording on H91XX Series DVRs

To enable motion recording on a 91XX series DVR, we must first configure motion detection. After motion detection is enabled, we will change our recording settings to match.

Configure Motion Detection

- 1. Go to Main Menu
- 2. Go to Device
- 3. Go to Motion
- 4. Enable Motion

5. Choose Sensitivity Level. The higher the number, the more sensitive the camera is.

6. Copy Settings to All channels.

Configure Recordings Settings

- 1. Go to Main Menu
- 2. Go to Record
- 3. Change Record Mode from "Always" to "Schedule"
- 4. Click "Schedule"
- 5. Click "Alarm"
- 6. Highlight all boxes as Red
- 7. Copy Settings to All Channels.

If you go to the live feed, you should now see the cameras and the letter M on the screens when they detect motion. Unique solution ID: #1156 Author: Alex Crewell Last update: 2013-08-20 23:26