ZMD-DD-SBN4

My Camera Images are "Rolling"

Camera Images are "Rolling"

All DVRs

If the camera images are "Rolling" **and/or** the DVR is displaying in only black and white, the DVR Video System is in PAL mode. To change the Video System go into the Audio/Video Setup and change it from PAL to NTSC.

Unique solution ID: #1023
Author: Patricia Pyle
Last update: 2014-07-18 10:49

(c) 2026 Jeremy Schultz <itmanager@eptco.com> | 2026-11-23 20:21
URL: https://kb.zmodo.com/index.php?action=artikel&cat=2&id=24&artlang=en