

# **ZMD-DC-SBN6**

## **Reset Password to Factory Defaults for SBN4, SBN8, SBN6, SAN4, and SAN8**

To restore your password to factory defaults, you will need to jump the two pins on the motherboard as shown below.

To do this, you only need to use a flathead screwdriver or metal paper clip to connect the two pins together. Make sure the metal of the screwdriver or paper clip connects both pins to reset the password.

# ZMD-DC-SBN6



Unique solution ID: #1220

Author: Bryant Irwin

Last update: 2014-09-18 16:21